



# DOMETIC FRIDGE

The *Dometic CF-35 fridge* has 35 liters of space. When you pick up the van the fridge is set to cool to 37 degrees Fahrenheit. This is the best temperature to keep everything cold without freezing items at the bottom of the fridge. The fridge monitors the camper van's battery and will shut off before damaging the battery that would prevent the van from starting, so don't worry!



- To **Power On** the Dometic fridge, hold the power button until the LED screen illuminates and the current temperature appears. Press the set button to see what temp the fridge is set to and change it to your desired temperature using the plus & minus buttons.



Hold down the power button to turn on, push the set button to see where the temp is already set to.



Adjust to desired temp using plus and minus buttons and push "Set".

The power save mode on the fridge is activated when the voltage of the van batteries drops below a certain level. We set up the vans to ensure they run throughout the trip.

During the hot summer months, the fridge will pull more battery power to keep the fridge to the desired cooling temperature. If you are leaving your van during the summer crack a window to help.

## TIPS:

- If the van was parked all day, running the van for 20-30 minutes will help to charge up the batteries.
- The fridge has an **extra USB port** on the front for charging devices.

**Still not working?**  
**Call us at 1-866-222-5520**

